

LifePulse™ Furnace Monitoring Installation Instructions

OPERATING

Thank you for your purchase of LifeWhere™! This guide will help you understand how the LifePulse device works and how to install the LifePulse™ device safely.


The LifePulse™ is designed to be installed in a junction box next to the shut off switch for your Furnace. The LifePulse™ device must be connected to your home network in order to send data to the LifeWhere™ cloud for processing.




INSTALLATION

- 1 Turn off the power to the Furnace at the main circuit breaker or fuse panel.
- 2 Unscrew and remove the switch plate cover to the Furnace main switch.
Unscrew the switch from the electrical box and pull out the wires still attached. Use a voltage tester to ensure the circuit is dead.
- 3
- 4 Rewire the Hot LOAD wire from the switch to the Hot OUT port on the LifePulse.
- 5 Rewire the Neutral LOAD wire to the Neutral OUT port on the LifePulse
- 6 Rewire the Neutral LINE wire to the Neutral IN port on the LifePulse™
- 7 Add a new wire from the Light Switch Hot LOAD to the the Hot IN port on the LifePulse
- 8 Attach the ground wires to the ground screw in the junction box.

Wiring Diagram for a Furnace Only



Wiring Diagram for a Furnace and Accessory (Humidifier, etc.)



FCC Compliance



This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

UL Certified



120V
15A

WiFi Compatibility

